





Kitchen Elevations

The heights displayed represent the typical minimum and maximum heights for kitchen cabinets. We can adjust upper cabinet heights to fit any height in-between.



Please Note: Dishwasher and Fridge openings require end panels which add 1 1/2" to space required.